

1/10




FIG. 1




FIG. 2

2/10




FIG. 3




FIG. 4

3/10




FIG. 5




FIG. 6

4/10




FIG. 7




FIG. 8

5/10




FIG. 9




FIG. 10

6/10




FIG. 11




FIG. 12

7/10




FIG. 13




FIG. 14

8/10




FIG. 15






FIG. 16



9/10





*FIG. 17*




*FIG. 18*


10/10

*FIG. 19*

• = stop marking for D and E

A = compact cylinder  100 %

B = compact  > 50 % ; tube < 50 %

C = compact   $\approx$  20 % ; tube  $\approx$  80 %

D = tube  = 100 % according to the invention

E = tube  > 120 % according to the invention

BLK (bone-implant contact) = E > D > C > B > A

*FIG. 20*